## **Outlet Stations** cross + protection

## PORTER

	6100-1	<b>Single Oxygen Outlet Station</b> Requires Hose, O <sub>2</sub> , diss/Porter listed on page 9
	C6200-1	Dual Outlet Station, O2 /N2O
	6250K	Exposed Cover for 6100-1/C6200-1
	6300-1	Floor Mounted Outlet Station
	6256-3	Triple Outlet
		O2 /N2O/Vacuum
	6257-3	<b>Exposed Triple Outlet</b> O <sub>2</sub> /N <sub>2</sub> O/Vacuum
0		
	6255-1	<b>Compact Wall Triple Outlet</b> O2 /N2O/Vacuum
8	6258-1	Compact Triple Outlet
		for Cabinets (no hoses)
	6258-3	Compact Triple Outlet
	0100 0	for Cabinets
		with 3 foot hoses and shut offs
and the second s	6258-5	Compact Triple Outlet
	0230-3	for Cabinets
		with 5 foot hoses and shut offs
$\longrightarrow$	5602	Vacuum Quick Connect
		Connects new in-line
		vacuum monitor to outlet
Π	5600-3	Vacuum Outlet Station